

Data Declaration System

What's new in Version 20.1?

Apr 10th 2020

DDS Contact

email: hotline@visu-it.com

Internet: visu-it.de/products/dds/



© Copyright 2020

Visual Information Technologies GmbH

An der Schergenbreite 1

93059 Regensburg

Contents

1 Purpose and scope	3
2 What's new in Version V20.1.R0?.....	3
2.1 Features.....	3
ExpA2.....	3
GenEdit.....	3
ImpA2.....	3
ImpADD	3
2.2 Improvements / Correction of Bugs	4
SysConf:	4
3 No longer supported filters/components	4
ExpMSR.....	4
• ADDS-16469: Removed MSRSW2html tool from DDS suite.	4
4 Questions?.....	4

1 Purpose and scope

This document describes the improvements and changes made in DDS V20.1.

2 What's new in Version V20.1.R0?

Improvements and changes of DDS V20.1.R0 compared to previous.

2.1 Features

ExpA2

- ADDS-16292: Support of ASAP2 standard version 1.71
- ADDS-15889: Support of CALIBRATION_ACCESS attribute according to Asap2 1.7.1 specification (CALIBRATION, NO_CALIBRATION, NOT_IN_MCD_SYSTEM, OFFLINE_CALIBRATION)
- ADDS-17037: Support of protocol "XCPplus V1.2"

GenEdit

- ADDS-13195: Show about the tool architecture information (32-/64 Bit) on the system-info dialog.

ImpA2

- ADDS-16378: New Asap2Parser Version 9.1 in order to support Asap2 version 1.7.1.
- ADDS-15889: Support of CALIBRATION_ACCESS attribute according to Asap2 1.7.1 specification (CALIBRATION, NO_CALIBRATION, NOT_IN_MCD_SYSTEM, OFFLINE_CALIBRATION)
- ADDS-17039: [ImpA2] Fixed rare crash when importing an invalid *.a2l file.
- ADDS-17037: Support of protocol "XCPplus V1.2"

ImpADD

- ADDS-15558: Avoid error messages of type L2522 and L2520 referring to incompletely configured units from ADD (especially in the import-offline case).
- ADDS-15889: Support of CALIBRATION_ACCESS attribute according to Asap2 1.7.1 specification (CALIBRATION, NO_CALIBRATION, NOT_IN_MCD_SYSTEM, OFFLINE_CALIBRATION)

2.2 Improvements / Correction of Bugs

SysConf:

3 No longer supported filters/components

ExpMSR

- ADDS-16469: Removed MSRSW2html tool from DDS suite.

4 Questions?

If you have any questions about this release, please contact the Visu-IT! DDS Hotline:

DDS Hotline

Tel.: +49 (0)941 / 49082 - 16
email: hotline@visu-it.com



DDS Product page

visu-it.de/products/dds/